


HOW IT WORKS



COBRA VIEW

SEE. CLEAN. IMPRESS.



COBRA VIEW CAMERA



SEE. CLEAN. IMPRESS.


HYPERVAC

TOOLS THAT MAKE YOU BETTER.
HYPERVAC.COM

CALL TOLL FREE: 1-866-315-5777

DISCOVER MORE: HYPERVAC.COM

HYPERVAC



FORWARD SKIP CAM

Designed to blow debris from the register down into the main trunk line. Wireless transmitter can transmit up to 10 feet to the wireless monitor. Uses lithium rechargeable battery, lasting up to 3 hours on a charge. Standard definition camera head uses white LED light to give a clear picture of the inside ductwork. Designed mainly for small 4-6 inch vent runs.



LED LIGHTS

Forward Skip Cam uses white LED lights which work better in smaller vent runs.



INFRARED CAMERA


The Magnet Cam uses infrared to see further down the vent runs.



MAGNET CAMERA

Designed to Magnetize to the main trunk line, the camera head fits through 1" holes. Simply cut an extra hole next to where you would enter your agitation whips and you will be able to see the cleaning action.

Flexible head allows for quick angle changes when on the job.



5" WIRELESS MONITOR

Lithium rechargeable battery inside. Lasts up to 3 hours on one charge.

RARE EARTH MAGNETS

2 magnets on the top and one on the side allow for the camera to be easily placed on the metal ductwork.



ON/OFF SWITCH

FORWARD SKIP BALL

Forward Skip Cam uses a standard forward blowing skip ball that can be removed allowing other agitation tips to be installed.